

POPCORN POPPER

Operating Instructions

Controls and their functions

- Light and Warmer Switch
Turns on the heat to the bottom corn pan and heat light
- Kettle Motor Switch
Turns on the motor which drives kettle agitator shaft
- Kettle Heat Switch
Turns on the heat element

Amount of popcorn and oil

Use one pre-measured packet of corn/ oil

Or

6 oz. of popcorn and 1.6-2.0 ounces of oil (coconut oil stays fresh longer)

Popping Instructions:

1. Turn KETTLE HEAT and KETTLE MOTOR switch ON
2. Make test pop with 3 kernels of corn and 1 ounce of oil
3. Load pre-measured popcorn and oil pouch into kettle
4. When corn has popped, dump kettle
5. Repeat cycle starting with #3; always pop 3-5 batches for best popcorn.



WARNING: to avoid serious burns, do not touch the kettle while it is hot.