

455 Pease Road
Burlington, WA 98233
(360) 707-2115
Fax (360) 707-0414

Pacific Party Canopies^{INC}


Covering All Your Rental Needs

www.pacificpartycanopies.com

Chafing Dish Use Instructions

Hot Foods:

1. Remove all components from the box and unwrap.
2. Place base on firm surface (see diagram for included parts).
3. Carefully place fuel holders at center of base. Caution: always use a hot pad when touching the fuel holder. Fuel, fuel holders and fuel holder lids can get extremely hot.



4. Set water pan into base and fill with water (fill with hot water for faster heating).

5. Remove the cover from the fuel canister, light the fuel and allow water to heat (steam from the heated water will keep the food hot).

6. Place food in the food pan and set this pan into the water pan. The food pan will be suspended above the water. Place the cover over the food pan.

7. To extinguish fuel, replace cover over fuel burner—DO NOT BLOW OUT. *(For best heat efficiency, keep cover placed over food pan. Periodically check water level, as water will evaporate as it turns to steam.)*

Cold Foods:

Follow the above directions for assembly, but use crushed ice or an ice and water mixture in the water pan.